



Standards for Block And Lot Numbering

1. Lot count should not be a continuous count from the previous Block. (Ex: 50 Unit Subdivision, Block 1 Lots 1-15, Block 2 Lots 1-20, Block 3 Lots 1-10, Block 4 Lots 1-5). With the new Block creation, the Lot count should start back at 1.
2. All open space lots should be indicated with a Lot numbering of 900.
3. Amending plats should be accompanied with the letter "A" after its new Lot #
4. Replats should be accompanied with the letter "R" after its new Lot #